

TRBOnet Enterprise. RadioServer System Requirements v 1.0

Before installing TRBOnet RadioServer, make sure that your system meets the following minimum hardware and software requirements:

Hardware Computer Requirements

| | |
|---------------------------|---|
| Platform | 32 bit Pentium III (Pentium IV recommended) or compatible processor |
| Memory | Minimum 512 MB |
| Hard Disk Space | Minimum 50 MB of disk space for a full installation, which includes up to 25 MB of temporary setup files that are removed automatically at completion of install. Additional hard disk space is required for audio recordings. |
| Additional Devices | Multichannel sound card. Recommended: M-Audio 1010 LT http://www.m-audio.com/products/en_us/Delta1010LT.html |

Software Radio Requirements

| | |
|-------------------------|--|
| Operating System | Microsoft Windows XP Professional Service Pack 2, Vista Business SP1 |
| Database | MS SQL Server 2000/2005/2008 Express Edition or higher |
| Additional | MOTOTRBO RNDIS Multichannel Device |

Master Radio Requirements

It is recommended to use a radio with display (DM 3600/3601, XPR 4500/4550) as master radios to be able to receive EMERGENCY CALL. Any other MOTOTRBO radio can be used as an additional radio for Revert GPS capabilities. The required firmware version is 1.04.03 or higher

The modified cable connectors are required in order to be able to operate with voice capabilities. The schema is available at http://trbonet.com/pdf_files/trbonet_mototrbo_radio_connector_firmware143.pdf