

How to install TRBOnet on single PC.

Sound cards configuration.


The document describes how to install RadioServer and DispatcherConsole on single PC. The solution is also applicable for TRBOnet Standard. The computer with two sound cards is required.

1. Install the additional (second) sound card into the computer. It is recommended to use the following equipment:

- Creative Audigy SE – internal, PCI for desktop computers (30\$)
- Creative Sound Blaster Connect – external, USB 1.1 for laptops (60\$)

Note: do not use a sound card based on chipset CMI audio as an additional sound card!

2. Open “Sounds and Audio Devices”. Select the integrated sound card as default on tabs “Audio” and “Voice”. This sound card will be used for DispatcherConsole. Attach the microphone and headphones to the computer. These devices will be used for a dispatcher.



3. Run RadioServer Configuration(in case of Standard, launch console and go to Main Menu/Tools/RadioServer Options). Select the additional sound card as a device for recording and playback on the tab “Audio”. Attach the master device audio input/output to the additional sound card.

